



S0 = 'OFF' push button
 S1 = 'ON' push button
 K1 = Line contactor
 K2 = Stat contactor
 K3 = Delta contactor
 K4 = Star delta timer
 F2 = Overload relay
 F1 = Backup fuse